

## Assembly Instructions for Spacer Panel

### Model number

VCTS-51U-6	VCTS-51U-8	VCTS-51U-10	VCTS-51U-12
VCTS-47U-6	VCTS-47U-8	VCTS-47U-10	VCTS-47U-12
VCTS-44U-6	VCTS-44U-8	VCTS-44U-10	VCTS-44U-12
VCTS-42U-6	VCTS-42U-8	VCTS-42U-10	VCTS-42U-12
VCTS-24U-6	VCTS-24U-8	VCTS-24U-10	VCTS-24U-12

### Hardware

Qty. (8), 1/4-20 x 3/8" Pan Head Phillips Screw

### Tools

Screwdriver (Phillips)

If frame's main rails have two holes, use the one on the inside (as shown)

